

Interface of Abutment screw

Europe&USA 



Nobel BioCare

Interface Shape & Torque of Screw

Star-shaped

 System: Replace(Triangle)
Size: NP





Front View of Screw

Screwdriver: Original Star-shaped Screwdriver

Interface Shape & Torque of Screw

Star-shaped

 System: Replace(Triangle)
Size: RP

 System: Replace(Triangle)
Size: WP

 System: Replace(Triangle)
Size: 6.0




Front View of Screw

Screwdriver: Original Star-shaped Screwdriver

Interface Shape & Torque of Screw

Star-shaped

 System: Active/CC/PMC(Hexagon)
Size: NP




Front View of Screw

Screwdriver: Original Star-shaped Screwdriver

Interface Shape & Torque of Screw

Star-shaped

 System: Active/CC/PMC(Hexagon)
Size: RP

 System: Active/CC/PMC(Hexagon)
Size: WP




Front View of Screw

Screwdriver: Original Star-shaped Screwdriver

Interface Shape & Torque of Screw

Star-shaped

 System: Active(Hexagon)
Size: 3.0




Front View of Screw

Screwdriver: Original Star-shaped Screwdriver

Straumann

Interface Shape & Torque of Screw

Torx

 System: Tissue Level-R
Size: RN

 System: Tissue Level-R
Size: WN





Front View of Screw

Screwdriver: Original Torx Screwdriver

Interface Shape & Torque of Screw

Torx

 System: Bone level-R
Size: NC

 System: Bone level-R
Size: RC



Front View of Screw

Screwdriver: Original Torx Screwdriver

Interface Shape & Torque of Screw

Torx

 System: ITI SC
Size: /



Front View of Screw

Screwdriver: Original Torx Screwdriver

Interface Shape & Torque of Screw

Torx

 System: BLX
Size: RB/WB




Front View of Screw


Screwdriver: Original Torx Screwdriver

Zimmer


Interface Shape & Torque of Screw

H1.25

 System: Tapered Screw-Vent
Size: 3.5

 System: Tapered Screw-Vent
Size: 4.5

 System: Tapered Screw-Vent
Size: 5.7



Hexagon




Front View of Screw

Screwdriver: H1.25

Interface Shape & Torque of Screw

H1.25

 System: Azure
Size: 3.5/4.0



Hexagon



Front View of Screw

Screwdriver: H1.28

Interface Shape & Torque of Screw

H1.28

 System: Azure
Size: 4.5/5.0



Hexagon



Front View of Screw

Screwdriver: H1.28

Interface Shape & Torque of Screw

H1.25

 System: Eztetic
Size: NP



Hexagon




Front View of Screw


Screwdriver: H1.25


Biomet 3i

Interface Shape & Torque of Screw


H1.20

 System: Certain
Size: 3.4

 System: Certain
Size: 4.0

 System: Certain
Size: 5.0

 System: Certain
Size: 6.0



Hexagon




Front View of Screw


Screwdriver: H1.20


Bego

Interface Shape & Torque of Screw


H1.25

 System: S/RI (PM)
Size: 3.25/3.75

 System: S/RI (PM)
Size: 4.1

 System: S/RI (PM)
Size: 4.5

 System: S/RI (PM)
Size: 5.5



Hexagon



Front View of Screw


Screwdriver: H1.25

Astra

Interface Shape & Torque of Screw

H1.28

 System: Osseo Speed™-TX
Size: 3.0



Hexagon




Front View of Screw

Screwdriver: H1.28

Interface Shape & Torque of Screw

H1.28

 System: Osseo Speed™-TX
Size: 3.5/4.0



Hexagon




Front View of Screw

Screwdriver: H1.28

Interface Shape & Torque of Screw

H1.28

 System: Osseo Speed™-TX
Size: 4.5/5.0



Hexagon




Front View of Screw

Screwdriver: H1.28


Interface Shape & Torque of Screw

H1.28

 System: Osseo Speed™ EV
Size: 3.0



Hexagon




Front View of Screw

Screwdriver: H1.28

Interface Shape & Torque of Screw

H1.28

 System:Osseo Speed™ EV
Size: 3.6



Hexagon




Front View of Screw

Screwdriver: H1.28

Interface Shape & Torque of Screw

H1.28

 System:Osseo Speed™ EV
Size: 4.2



Hexagon




Front View of Screw

Screwdriver: H1.28

Interface Shape & Torque of Screw

H1.28

 System:Osseo Speed™ EV
Size: 4.8

 System:Osseo Speed™ EV
Size: 5.4



Hexagon




Front View of Screw


Screwdriver: H1.28

SIC

Interface Shape & Torque of Screw

H1.20

 System:ace/max/tapered
Size: 3.3

 System:ace/max/tapered
Size: 4.2



Hexagon



Front View of Screw

Screwdriver: H1.20

ICX

Interface Shape & Torque of Screw

H1.40

 System:Premium/ACTIVE LIQUID
/ACTIVE-MASTER
Size: BL



Hexagon



Front View of Screw

Screwdriver: H1.40

Anthogyr

Interface Shape & Torque of Screw

H1.20

 System:REG/PX
Size: R



Hexagon



Front View of Screw


Screwdriver: H1.20

Ankylos

Interface Shape & Torque of Screw

H1.00

 System:C
Size: R



Hexagon




Front View of Screw

Screwdriver: H1.00

XIVE

Interface Shape & Torque of Screw


H1.22

 System:xive-s plus
Size: 3.4

 System:xive-s plus
Size: 3.8

 System:xive-s plus
Size: 4.5

 System:xive-s plus
Size: 5.5



Hexagon



Front View of Screw

Screwdriver: H1.22

Camlog


Interface Shape & Torque of Screw

H1.28

 System:Camlog (COMFOUR™)
Size: 3.3

 System:Camlog (COMFOUR™)
Size: 3.8

 System:Camlog (COMFOUR™)
Size: 4.3



Hexagon




Front View of Screw

Screwdriver: H1.28

Interface Shape & Torque of Screw

H1.28

 System:Camlog (COMFOUR™)
Size: 5.0



Hexagon







Front View of Screw

Screwdriver: H1.28

Interface Shape & Torque of Screw

H1.28

-  System:Conelog(COMFOUR™)
Size: 3.3
-  System:Conelog(COMFOUR™)
Size: 3.8
-  System:Conelog(COMFOUR™)
Size: 4.3



Hexagon



Front View of Screw

Screwdriver:H1.28

Interface Shape & Torque of Screw

H1.28

-  System:Conelog(COMFOUR™)
Size: 5.0



Hexagon








Front View of Screw


Screwdriver:H1.28

Thommen

Interface Shape & Torque of Screw

Torx

-  System:SPI
Size: 3.5
-  System:SPI
Size: 4.0
-  System:SPI
Size: 4.5
-  System:SPI
Size: 5.0
-  System:SPI
Size: 6.0









Front View of Screw


Screwdriver:Original Torx Screwdriver

Sweden&Martina

Interface Shape & Torque of Screw

H1.28

-  System:premium
Size: 3.3
-  System:premium
Size: 3.8
-  System:premium-one
Size: 3.3
-  System:premium-one
Size: 3.8
-  System:premium-one
Size: 4.3
-  System:premium-one
Size: 5.0



Hexagon






Front View of Screw

Screwdriver:H1.28

Interface Shape & Torque of Screw

H1.28

-  System:premium
Size: 4.3
-  System:premium
Size: 5.0



Hexagon



Front View of Screw


Screwdriver:H1.28

B&B

Interface Shape & Torque of Screw

H1.28

-  System: /
Size: M



Hexagon



Front View of Screw

Screwdriver:H1.28

Interface Shape & Torque of Screw

H1.28

-  System:EV/3P/WIDE
Size: R



Hexagon




Front View of Screw


Screwdriver:H1.28

C tech

Interface Shape & Torque of Screw

H1.28

-  System: EL
Size: /



Hexagon




Front View of Screw


Screwdriver:H1.28

Biohorizons

Interface Shape & Torque of Screw

H1.25

-  System: /
Size: 3.0
-  System: /
Size: 3.5
-  System: /
Size: 4.5
-  System: /
Size: 5.7



Hexagon




Front View of Screw

Screwdriver:H1.25

Biodenta

Interface Shape & Torque of Screw

H1.25

 System: Bone Level

Size: B0



Hexagon



Front View of Screw

Screwdriver:H1.25

Interface Shape & Torque of Screw

H1.25

 System: Bone Level

Size: B1



Hexagon



Front View of Screw

Screwdriver:H1.25

Interface Shape & Torque of Screw

H1.25

 System: Bone Level

Size: B2



Hexagon




Front View of Screw

Screwdriver:H1.25


ZUGA

Interface Shape & Torque of Screw


H1.35

 System: /

Size: 3.5

 System: /

Size: 4.3

 System: /

Size: 5.0



Hexagon




Front View of Screw

Screwdriver:H1.35

Neoss

Interface Shape & Torque of Screw

Star-shaped

 System: /

Size: 3.25



Front View of Screw

Screwdriver:Original Star-shaped Screwdriver

Interface Shape & Torque of Screw

Star-shaped

 System: /

Size: R



Front View of Screw

Screwdriver:Original Star-shaped Screwdriver

CLC

Interface Shape & Torque of Screw

H1.28

 System: CONIC

Size: /



Hexagon



Front View of Screw

Screwdriver:H1.28


Neodent

Interface Shape & Torque of Screw

Star-shaped

 System: GM

Size: /



Front View of Screw

Screwdriver:Original Star-shaped Screwdriver

Bredent

Interface Shape & Torque of Screw


Torx

 System:SKY

Size: NP

 System:SKY

Size: RP




Front View of Screw

Screwdriver:Original Torx Screwdriver


Implant direct

Interface Shape & Torque of Screw

H1.25

 System: LEGACY™4

Size: 3.0



Hexagon




Front View of Screw


Screwdriver: H1.25

Interface Shape & Torque of Screw

Torx

 System: InterActive™

Size: 3.0



Front View of Screw

Screwdriver: Original Torx Screwdriver

Interface Shape & Torque of Screw

Torx

 System: InterActive™

Size: 3.4



Front View of Screw

Screwdriver: Original Torx Screwdriver


BIOTECH

Interface Shape & Torque of Screw

H1.20

 System: KONCAT S

Size: 3.0



Hexagon



Front View of Screw


Screwdriver: H1.20

Interface Shape & Torque of Screw


H1.20

 System: KONCAT S

Size: 4.0

 System: KONCAT S

Size: 5.0

 System: KONCAT S

Size: 6.5



Hexagon



Front View of Screw

Screwdriver: H1.20

Ratio

Interface Shape & Torque of Screw


H1.35

 System: /

Size: mini

 System: /

Size: S/RP

 System: /

Size: L/WP



Hexagon




Front View of Screw

Screwdriver: H1.35

LEADER

Interface Shape & Torque of Screw


H1.20

 System: BL

Size: 3.4

 System: BL


Size: 3.75

 System: BL

Size: 4.5

 System: BL

Size: 5.0



Hexagon



Front View of Screw

Screwdriver: H1.20

OSSTEM

Interface Shape & Torque of Screw

H1.20

 System: GS/TS
Size: R



Hexagon




Front View of Screw

Screwdriver:H1.20

Interface Shape & Torque of Screw

H1.20

 System: GS/TS
Size: M



Hexagon



Front View of Screw


Screwdriver:H1.20

Interface Shape & Torque of Screw

H1.20

 System:SS
Size: 4.8

 System:SS
Size: 6.0



Hexagon



Front View of Screw


Screwdriver:H1.20

Dentium

Interface Shape & Torque of Screw

H1.28

 System: Super Line
Size: R



Hexagon





Front View of Screw

Screwdriver:H1.28

Interface Shape & Torque of Screw

Square

 System:NR Line
Size: /



Front View of Screw


Screwdriver:Original Square Screwdriver

Interface Shape & Torque of Screw


H1.28

 System:Simple Line
Size: R

 System:Simple Line
Size: W



Hexagon



Front View of Screw



Screwdriver:H1.28

DIO

Interface Shape & Torque of Screw

Torx

 System: SM Torx
Size: N





Front View of Screw

Screwdriver:Original Torx Screwdriver

Interface Shape & Torque of Screw

Torx

 System:SM Torx
Size: R/W




Front View of Screw

Screwdriver:Original Torx Screwdriver

Interface Shape & Torque of Screw

H1.20

 System:UF II
Size: 3.0



Hexagon



Front View of Screw

Screwdriver:H1.20

Interface Shape & Torque of Screw

H1.20

 System:UF II
Size: R/W



Hexagon




Front View of Screw

Screwdriver:H1.20

Megagen

Interface Shape & Torque of Screw

H1.20

 **System:** EZ PIUS

Size: M



Hexagon



Front View of Screw

Screwdriver: H1.20

Interface Shape & Torque of Screw

H1.20

 **System:** EZ PIUS

Size: R/W



Hexagon



Front View of Screw

Screwdriver: H1.20

Interface Shape & Torque of Screw

H1.20

 **System:** Any Ridge

Size: /



Hexagon




Front View of Screw

Screwdriver: H1.20

Interface Shape & Torque of Screw

H1.20

 **System:** Mini

Size: /



Hexagon



Front View of Screw

Screwdriver: H1.20

Interface Shape & Torque of Screw

H1.20

 **System:** Any One

Size: /



Hexagon




Front View of Screw

Screwdriver: H1.20

Dentis

Interface Shape & Torque of Screw

H1.25

 **System:** Dentis-SQ

Size: R



Hexagon




Front View of Screw

Screwdriver: H1.25

Interface Shape & Torque of Screw

H1.25

 **System:** Dentis-SQ

Size: M



Hexagon




Front View of Screw

Screwdriver: H1.25


NeoBiotech

Interface Shape & Torque of Screw

H1.20

 **System:** IS

Size: R



Hexagon



Front View of Screw

Screwdriver: H1.20

SG

Interface Shape & Torque of Screw

H1.20

 **System:** SST

Size: /



Hexagon




Front View of Screw

Screwdriver: H1.20

S NUC

Interface Shape & Torque of Screw

H1.20

 **System:** /

Size: M



Hexagon



Front View of Screw


Screwdriver: H1.20

Interface Shape & Torque of Screw

H1.20



System: /
Size: R



Hexagon



Front View of Screw

Screwdriver:H1.20


INNO/CWM

Interface Shape & Torque of Screw

H1.25



System: /
Size: /



Hexagon



Front View of Screw

Screwdriver:H1.25


CSM

Interface Shape & Torque of Screw

H1.20



System: /
Size: N



Hexagon



Front View of Screw


Screwdriver:H1.20

Interface Shape & Torque of Screw

H1.20



System: /
Size: R



Hexagon



Front View of Screw

Screwdriver:H1.20


Warantec

Interface Shape & Torque of Screw

H1.20



System: IT-R
Size: R



Hexagon



Front View of Screw

Screwdriver:H1.20

Interface Shape & Torque of Screw

H1.20



System: IU-R

Size: R



Hexagon



Front View of Screw

Screwdriver: H1.20

ZENOIS


Interface Shape & Torque of Screw

H1.20



System: /

Size: R



Hexagon



Front View of Screw


Screwdriver: H1.20

Interface Shape & Torque of Screw

Star-shaped

System: CloseFit

Size: UNP



Front View of Screw


Screwdriver: Original Star-shaped Screwdriver

Interface Shape & Torque of Screw

Star-shaped

System: CloseFit

Size: NP



Front View of Screw

Screwdriver: Original Star-shaped Screwdriver

Interface Shape & Torque of Screw

H1.25

System: Touareg-OS/S

Size: R



Hexagon



Front View of Screw

Screwdriver: H1.25

Interface Shape & Torque of Screw

H1.27

System: Seven-Lance

Size: M



Hexagon



Front View of Screw

Screwdriver: H1.27

Interface Shape & Torque of Screw

H1.27

System: Seven-Lance

Size: R

System: Seven-Lance

Size: W



Hexagon



Front View of Screw


Screwdriver: H1.27

Interface Shape & Torque of Screw

H1.27

System: C1

Size: NP



Hexagon



Front View of Screw

Screwdriver: H1.27

Interface Shape & Torque of Screw


H1.27

System: C1

Size: SP

System: C1

Size: WP



Hexagon



Front View of Screw

Screwdriver: H1.27

Interface Shape & Torque of Screw

H1.25

System: Conical Connection

Size: RP

System: Conical Connection

Size: NP



Hexagon



Front View of Screw


Screwdriver: H1.25

Interface Shape & Torque of Screw

H1.25

System: Conical Connection

Size: WP



Hexagon



Front View of Screw

Screwdriver: H1.25

Interface Shape & Torque of Screw

H1.25

System: SPI/DFI


Size: M

System: ICE/SPI/DFI

Size: R

System: SPI/DFI

Size: W



Hexagon



Front View of Screw


Screwdriver: H1.25

Interface Shape & Torque of Screw

H1.25

System: Classic/Prestige

Size: R



Hexagon



Front View of Screw

Screwdriver: H1.25

Datsing

Interface Shape & Torque of Screw

H1.20



System: Datsing (I)
Size: M



Hexagon



Front View of Screw

Screwdriver: H1.20

Interface Shape & Torque of Screw

H1.20



System: Datsing (I)
Size: R



Hexagon



Front View of Screw

Screwdriver: H1.20

Anker

Interface Shape & Torque of Screw

H1.20



System: SB-I/SB-II/SB-III
Size: N



Hexagon



Front View of Screw

Screwdriver: H1.20

Interface Shape & Torque of Screw

H1.20



System: SB-I/SB-II/SB-III
Size: R



Hexagon



Front View of Screw

Screwdriver: H1.20


wego

Interface Shape & Torque of Screw

H1.30



System: /
Size: N



Hexagon



Front View of Screw

Screwdriver: H1.30

Interface Shape & Torque of Screw

H1.30



System: /
Size: R



Hexagon



Front View of Screw

Screwdriver: H1.30

CANSUN/TAISHAN

Interface Shape & Torque of Screw

Torx



System: TK-GY
Size: M



Front View of Screw


Screwdriver: Original Torx Screwdriver

Interface Shape & Torque of Screw

Torx



System: TK-GY
Size: R



Front View of Screw

Screwdriver: Original Torx Screwdriver


Dental Master

Interface Shape & Torque of Screw

Star-shaped



System: DM
Size: NP



Front View of Screw


Screwdriver: Original Star-shaped Screwdriver

Interface Shape & Torque of Screw

Star-shaped



System: DM
Size: RP



Front View of Screw

Screwdriver: Original Star-shaped Screwdriver

Interface Shape & Torque of Screw

Star-shaped



System: DM
Size: 3.0



Front View of Screw

Screwdriver: Original Star-shaped Screwdriver


LeadOss

Interface Shape & Torque of Screw

H1.20



System: BL
Size: N



Hexagon



Front View of Screw


Screwdriver: H1.20

Interface Shape & Torque of Screw

H1.20



System: BL
Size: R



Hexagon



Front View of Screw

Screwdriver: H1.20


CASANGELS

Interface Shape & Torque of Screw

H1.25



System: /
Size: NP



Hexagon



Front View of Screw


Screwdriver: H1.25

Interface Shape & Torque of Screw

H1.25



System: /
Size: RP



Hexagon



Front View of Screw

Screwdriver: H1.25

KYOCERA

Interface Shape & Torque of Screw

Torx



System: BL
Size: NP



Front View of Screw


Screwdriver: Original Torx Screwdriver

Interface Shape & Torque of Screw

Torx



System: BL
Size: RP



Front View of Screw


Screwdriver: Original Torx Screwdriver

Interface Shape & Torque of Screw

Torx



System: BL
Size: WP



Front View of Screw

Screwdriver: Original Torx Screwdriver



MY Digital
Implant

For more details:
<https://m6cadcam-dental.com/>