

USER'S MANUAL

LED Beam+Wash 19x15W RGBW Zoom Lighting



-Maintenance

- 1.Please keep the light in dryness and avoiding use in wet place.**
- 2.Using intermittently can be extended the life.**
- 3.Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.**
- 4.Please do not wipe the crust using organic menstruum for avoid to damaged the product.**

-Statement

The product has well capability and intact packing when leave factory,All of the user should comply with above warning item and manual ,any misuse cause of the damages are not included in our guarantee,and also can't be responsible for any malfunction & problem owing to ignore the manual.

Please forgive that we will not be notice for technical change

-Attention Item

- 1.For guarantee the life of product,please do not put it on the wet place and not use it the place over 40 degree.**
- 2.Please don't lay the product on the un-fixable or shakable place.**

3. Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.

4. Power supply should not be changed over $\pm 10\%$ while the light is using, it will be decreased the life of lamp if the power is too high, but it will be influenced the luminosity if the power is too low.

5. After power off, if it is need used again, please cool down over 20 minuter.

6. Please look round the manual for ensure the product can be used normally.

-Product Introduction

*** Power Supply: AC90--275V, 50--60HZ**

*** Power consumption: 285W**

*** Fixing lamp: LED 19×15W RGBW**

*** DMX-Control-channels: 24/16 DMX Channels**

*** Shuttle: Flash rate: 0--10HZ**

*** Dimmer: 0-100% mechanic dimmer**

*** Long Lifespan LEDs (more than 60,000 hours)**

*** Focusing angle: 8-55 degrees**

*** Lens angle: 15 degrees**

DMX Channel Summary-24 Channels Mode

Channel	Value	Features
CH1	0-255	X axis rotation
CH2	0-255	X-axis fine-tuning
CH3	0-255	Y axis rotation
CH4	0-255	Y axis fine-tuning
CH5	0-255	XY speed adjustment
CH6	0-255	focusing
CH7	0-255	Total light adjustment
CH8	0-255	Strobe
CH9	0-255	Red1 Dimmer
CH10	0-255	Green1 Dimmer
CH11	0-255	Blue1 Dimmer
CH12	0-255	White1 Dimmer
CH13	0-255	Red2 Dimmer
CH14	0-255	Green2 Dimmer
CH15	0-255	Blue2 Dimmer
CH16	0-255	White2 Dimmer
CH17	0-255	Red3 Dimmer
CH18	0-255	Green3 Dimmer
CH19	0-255	Blue3 Dimmer
CH20	0-255	White3 Dimmer
CH21	000-175 176-200 201-224 225-255	Preset color Program jump Program gradient Program pulse
CH22	0-255	Program speed adjustment
CH23	050-099 100-150 150-199 200-255	Activation CH21 Self-propelled mode(1) Self-propelled mode(2) Voice control mode
CH24	0-255	Rest

DMX Channel Summary-16 Channels Mode

Channel	Value	Features
CH1	0-255	X axis rotation
CH2	0-255	X-axis fine-tuning
CH3	0-255	Y axis rotation
CH4	0-255	Y axis fine-tuning
CH5	0-255	XY speed adjustment
CH6	0-255	Total light adjustment
CH7	0-255	Strobe
CH8	0-255	Red Dimmer
CH9	0-255	Green Dimmer
CH10	0-255	Blue Dimmer
CH11	0-255	White Dimmer
CH12	0-255	Focusing
CH13	000-175 176-200 201-224 225-255	Preset color Program jump Program gradient Program pulse
CH14	0-255	Program speed adjustment
CH15	050-099 100-150 150-199 200-255	Activation CH13 Self-propelled mode(1) Self-propelled mode(2) Voice control mode
CH16	0-255	Rest